

Professional Digital Timer

Key Features

- Digitally adjustable parameters
- Large 3" Display
- 4 level volume control
- Action time range 1-9 minutes (in one minute step)
- Rest time range 10-90 seconds (in 5 seconds step)
- Interval beep range 0-60 seconds (in 5 seconds step)
- Number of rounds range 1-99
- Pause facility at any instant





- ① — Speaker
- ② — View / Set Round Time (Minutes)
- ③ — View / Set Rest Time (Seconds)
- ④ — View / Set Number of Rounds
- ⑤ — View / Set Interval Beep Time (Seconds)
- ⑥ — Volume Down / Decrement Parameter
- ⑦ — Volume Up / Increment Parameter
- ⑧ — Stop / Reset
- ⑨ — Start / Pause
- ⑩ — Rounds / Minutes Digit
- ⑪ — Seconds Digit

Operation

Setting Round time- Push and release round time switch once to view the value stored in memory. Push and hold the switch to enter edit mode. The display will start blinking in edit mode. Set the required value using up / down switches. Press again round time to store the value. The display will stop blinking.

Setting Rest time- Push and release rest time switch once to view the value stored in memory. Push and hold the switch to enter edit mode. The display will start blinking in edit mode. Set the required value using up / down switches. Press again round time to store the value. The display will stop blinking.

Setting Interval time- Push and release interval time switch once to view the value stored in memory. Push and hold the switch to enter edit mode. The display will start blinking in edit mode. Set the required value using up / down switches. Press again interval time to store the value. The display will stop blinking.

Setting Number of rounds- Push and release rounds switch once to view the value stored in memory. Push and hold the switch to enter edit mode. The display will start blinking in edit mode. Set the required value using up / down switches. Press again rounds to store the value. The display will stop blinking.

Setting Volume level- When timer is in standby mode, push up or down switch to adjust the required volume level. The display will show L - 1(2, 3, 4)

Start / Pause- When timer is in standby mode, push start switch once to start the timer. Push again in running mode to pause.

Stop / Reset- When timer is in running mode, push Stop switch once to stop and reset the timer.

Note- When timer is in standby mode, it will display company logo (eg ABC SPORTS) on display. The dot will blink in work mode would be still in rest mode.